Smart Room Controller

Household Leak Detection

Use Case - Dishwasher leak

Fisher & Paykel 2 drawer dishwasher has a random leak from the bottom drawer.

The unit already has a water tray with leak sensor under the unit.

However the bottom drawer leak is happening outside the built-in leak detection area.

Leak is discovered because water runs from the dishwasher along the cabinet front and I end up stepping in the water.

Present solution is to lay out towels to catch the leak if it occurs.

The dishwasher






Components

- Teensy microcontroller 3.2 powered by USB to computer.
- Simple button (generic)
- Passive buzzer (Elegoo)
- Humidity sensor (Elegoo Temperature and Humidity Sensor DHT11)
- Ethernet Port (Wiznet Wiz820io)


Solution 1 - humidity sensor

- Place a cotton or sponge pad in a dish in the leak area
- Put the humidity sensor near the moisture collection area
- To conserve battery power for the sensor, user activates sensor when turning on the dishwasher. Sensor automatically deactivated after 2 hours (wash cycle complete)


Solution 1 - Flowchart



Solution 1 - Breadboard



Solution 1 - Schematic



Alternate Solutions - proposed by Mauricio

- Capacitive Sensor
 - Run wires along leak area to catch leak at source
 - Install camera to see where leak is occurring
- Laser Sensor
 - Aim at leak area to catch change in surface; i.e. water vs. no water

Manufactured Item - water tray

3D printed a small water collection tray to hold the moisture collector; cotton ball or small sponge.

FUTURE ITEM. NOT YET DONE.

Demo

- Moisten water collector
- 2. When humidity sensor value exceeds threshold
 - a. Buzzer will sound
 - b. Lights will flash
 - c. Fans will go on
- 3. Interrupt with button
 - a. All alerts will stop
- 4. Remove moisture collector
 - a. All alerts will stop